



Portal > Knowledgebase > Iridium > Iridium GO! > How-To > Sending a text message using the Iridium GO!

Sending a text message using the Iridium GO!

Lu Parente - 2017-09-27 - 0 Comments - in How-To

Follow the steps below on how to send a text message using the Iridium GO! application with the Iridium GO!.

Solution 1: Sending a text message to a cellular phone

1. Deploy the antenna to power on the Iridium GO!
2. The Iridium GO! will display bars of signal strength and begin searching for the network.
3. The Iridium GO! will display Searching followed by Iridium once the device has registered
4. Connect to the Iridium GO! Wi-Fi hotspot
5. Launch the Iridium GO! app on your smartphone
6. Login using the desired profile (Guest is default)
7. Select the Message icon
8. Select the New Message icon (top right corner)
9. In the To: field, enter the recipient number starting with a + or 00 followed by the country code, area code and phone number. I.e. +14162536008 or 0014162536008
10. In the Add message here field, enter the desired message.
11. Press Send when finished to send your text message.

Solution 2: Sending a text message an Iridium subscriber

1. Deploy the antenna to power on the Iridium GO!
2. The Iridium GO! will display bars of signal strength and begin searching for the network.
3. The Iridium GO! will display Searching followed by Iridium once the device has registered
4. Connect to the Iridium GO! Wi-Fi hotspot
5. Launch the Iridium GO! app on your smartphone
6. Login using the desired profile (Guest is default)

7. Select the Message icon
8. Select the New Message icon (top right corner)
9. In the To: field, enter the Iridium recipient number starting with a + or 00 followed by the full 8816 phone number. I.e. +881623412345 or 00881623412345
10. In the Add message here field, enter the desired message.
11. Press Send when finished to send your text message.