



Portal > Knowledgebase > Inmarsat > IsatPhone Pro > How-To > Placing a call from the IsatPhone Pro & IsatPhone 2

---

## Placing a call from the IsatPhone Pro & IsatPhone 2

Lu Parente - 2017-03-28 - in How-To

Follow the steps below on how to place a call from the IsatPhone Pro & Isatphone 2.

Step 1: Register to the network

1. Rotate and extend the antenna so it is pointing at the sky
2. Face towards the general direction of the equator and the phone will begin to register

**Note:** The Inmarsat satellites are geostationary and they do not change location. The satellites are positioned across the equator therefore you will need to ensure you are facing the satellite from your region. If you do not face the right direction you will not register to the network. The signal indicator will show bars, if it does not, turn 90 degrees to the right and continue doing so until you have achieved signal gain.

Step 2: Place a call

Press and hold the 0 key until the + appears

Dial the country code, area code and phone number

Example: + (country code)(area code/city code)(phone number)

Example: + 1 416 253 6008

---

### Related Pages

- [\[Video\] How-To with the IsatPhone 2](#)