



Portal > Knowledgebase > Iridium > 9505A Handset > How-To > Placing a call to Iridium 9505A

---

## Placing a call to Iridium 9505A

Lu Parente - 2014-04-24 - in How-To

Follow the steps below on how to place a call to the Iridium phone.

Solution 1: Dialling from a landline or cellular

1. To place a call to an Iridium phone you must have international dialling capabilities
2. From a North American landline or cellular dial, 011 followed by the 8816 number
  - Example: 011 8816 325 12345

Solution 2: Dialling from an Iridium phone to an Iridium phone

1. From the Iridium phone dial, + followed by the 8816 number.
2. To obtain the + sign, press and hold the 0 key until the + appears
3. Dial the Iridium satellite phone number and press OK
  - Example: + 8816 325 12345