



[Portal](#) > [Knowledgebase](#) > [Iridium](#) > [9505A Handset](#) > [How-To](#) > [Placing a call to the Iridium 9505A, 9555, Extreme, and Iridium GO!](#)

## Placing a call to the Iridium 9505A, 9555, Extreme, and Iridium GO!

Lu Parente - 2017-09-12 - in [How-To](#)

Follow the steps below on how to place a call to the Iridium 9505A, 9555, Extreme & Iridium GO!

### **Solution 1: Dialling from a landline or cellular**

1. To place a call to an Iridium phone you must have international dialling capabilities
2. From a North American landline or cellular dial, 011 followed by the 8816 number
  - o Example: 011 8816 325 12345

### **Solution 2: Dialling from an Iridium phone to an Iridium phone**

1. From the Iridium phone dial, + followed by the 8816 number.
2. To obtain the + sign, press and hold the 0 key until the + appears
3. Dial the Iridium satellite phone number and press the Green button
  - o Example: + 8816 325 12345