

## Receiving Email using Iridium Mail & Web for Android on Iridium GO!

Lu Parente - 2014-08-05 - in How-To

Follow the steps below on how to receive emails using the Iridium Mail & Web application for Android.


**Note:** Before following the instructions below, please ensure you have completed the setup and configuration instructions outlined in the [Iridium GO! Mail & Web Quick Start Guide for Android](#).

### **Solution: Receiving Email**


1. Launch the Iridium Mail & Web application.




2. Select Mail from the Iridium Mail & Web home screen.



3. Select Send/Receive Email



4. When you're ready to check for any new or undelivered email, ensure the Iridium GO! is registered to the network and it is maintaining at least 3 bars of signal strength. Select Send/Receive Email to establish the data connection and receive email messages.



- 5. The progress indicator and log will provide you with the necessary information to ensure any new or undelivered emails have been received successfully.